

Cilbond 41 Primer Usage in Bedliner Repairs

Note: Please read the MSDS and data sheets before using this product. State and local restrictions may apply.

Cilbond 41 primer is a plastics primer that was designed for cast molded plastics market but has proven to work very well with high pressure spray polyureas.

Cilbond 41 can be applied by brush, roller or spray. In most bedliner repairs a simple disposable brush or roller is the best way to go.

Prepare the repair area as needed with a solvent wipe and scuff with 40 grit paper. Brush on a light coat of Cilbond 41 (see the data sheet for directions). Coat the affected area as needed.

All repairs will differ and a judgment call will have to be made on the best way to proceed. A combination of masking, string-line, cutting and/or sanding to remove bad material, sanding edges to blend the repair area into the existing coating, texture, etc...

Be creative, you will find that polyurea is easy to work with and repairs can be done in a variety of ways as long as the finished product looks good and makes your customer happy.