


MH, MH2, MH3, MX2, MINI3, SUPERMAXI & VR'S




FAHRENHEIT

PRESS	DISPLAY	PRESS & HOLD	▲	▼	DISPLAY	RELEASE
▲▼	SET					
▲	LDC					
▲	rP					
▲	dSP					
▲	FAIL					
▲	I.Err					
▲	UNIT					
▲	Qt2					
▲	nLFI					
▲	PShI					
▲	PSLI					
▲	PL I					
▲	Ftbl					
▲	Ctrl					
▲	Qt 1					
▲	Ftr.E					
▲	SP.hi					
▲	SP.Lo					
▲	IS.En					
▲	S.dEC					
▲	C-F					
▲	L in					
▲	SEn					
▲	SET					
▲	LDC					
▲	rP					
▲	dSP					
▲	FAIL					
▲	I.Err					
▲	UNIT					
▲	dSP2					
▲	SIL2	SET	▲		on	
∞	SET TEMP					

Follow Press Column until you come to SIL2
 Press and Hold SET and push up arrow until
 On is displayed. Select Infinity Button until
 Set Temp. appears on display.

T/C

SD 31 CONTROLLER



J T/C

(+) WHT.

(-) BLK.

T T/C

(+) BLUE.

(-) RED.

CONNECT A JUMPER
ACROSS 10 & 11
HEAT MAT'L ABOVE
32 DEGREES
REMOVE JUMPER.